



SUBJECT: 43xx Master Reset

Applicable Models: 4310R, 4320R, 4350R and 43100R LCR Meter

Question: What is the Master Reset routine?

Answer: Press the top soft key button while the instrument is powering up.

Detail:

The Master Reset function can be used to resolve some problems which are caused when an instrument's internal logic enters an indeterminate state. Performing a Master Reset does not affect the calibration of the instrument.

- 1) Turn the 4300 off using the power button on the front panel.
- 2) Press the Top Soft Key button constantly and then press the Power button to power on the 4300. Keep pressing the Top Soft Key until the 4300 displays 'Restoring Default Parameters'.
- 3) Perform the Open Circuit and Short Circuit trims (AC + Rdc) using the 40150 Kelvin Clips which were supplied with the unit.

